


FITTING INSTRUCTIONS
27S & 27U
Alignment of Bushes
27S

Step 1:

Remove existing bushes ensuring to remove the outer metal sleeves.

Step 2:

Ensure the bore is clean from debris and contaminants.

Step 3:

Apply some washing up liquid or tyre soap to the outer bore of the bushes and push in from the direction show on the diagram.

Step 4:

Insert the inner metal sleeves.

Step 5:

Fit the arms back to the vehicle and torque to manufactures settings when the vehicle is at ride height.

**Front of
Vehicle**

