

Fitting Front Upper Arm 49A & Lower Arm 49B Polybushes



Bush Alignment

Once the front upper and/or lower arms have been removed, the O.E. rubber bushes must be extracted from the arm housings.

Your new bushes must be fitted with the encapsulated metal washer on the **outside of the arm** (A).

It is important to ensure that the inner surface of the bush housing is thoroughly clean before you new 49A or 49B Polybushes are fitted.

49A/49B Polybush

O.E. Bush

(A)



Use washing up liquid or tyre soap to fit. Copper Grease or similar products are not needed.