

**FITTING INSTRUCTIONS****27AW - Differential Mounting Bush****27AW Contains:**

2 x 27AW Upper Bushes  
2 x 27AX Lower Bushes  
2 x 44EC Tubes

**Step 1:**

Remove existing differential carrier bushes. Ensure there are no sharp edges left in the bore.

**Step 2:**

The existing lower stopper washer has to be reused by removing all old rubber.

A full restoration video has been uploaded to our YouTube page.

"Restoration of MK1 & 2 MX5 Diff Mounting Brackets - Before Fitting Polybush 27AW Diff Bush"

<https://www.youtube.com/watch?v=OpN48l6Fs9E&t=1s>

**Step 3:**

Insert the 27AW from the top and the 27AX from the bottom side.

**Step 4:**

Insert the tube through both bushes until flush with the top bush.

**Step 5:**

Lift the differential into place and align with the mounting bolts. Fit the lower stopper washer into the 27AX concaved underside, fit nut and torque to OEM recommended settings.

